

Monte Carlo Dose Calculations for Irradiation of Foods (meat) using Electrons and X-rays Beams.

Otsile Tikologo

Frank Laboratory of Neutron Physics (FLNP)

Project supervisor: A. Rogov

- 1 Aim(s)
- 2 Food Irradiation
- 3 FLUKA simulations
- 4 Outlook
- 5 Acknowledgements

Aim(s)

- Study how electron radiation interact with matter (meat) using FLUKA
- ~~Use FLUKA to design an optimal radiation shielding infrastructure for the Rhodotron facility~~

- Use of ionizing radiation (electrons, X-rays and gamma rays) to reduce the population of, or prevent the growth of, undesirable biological micro-organisms in food.
- Sources of ionizing radiation:
 - Radioactive isotopes
 - Electron accelerators

Food Irradiation

- Use of ionizing radiation (electrons, X-rays and gamma rays) to reduce the population of, or prevent the growth of, undesirable biological micro-organisms in food.
- Sources of ionizing radiation:
 - Radioactive isotopes
 - Electron accelerators



Principle Applications of Food Irradiation

- Low dose (up to 1 kGy):
 - Inhibit sprouting
 - Delay ripening of fruits



Principle Applications of Food Irradiation

- Low dose (up to 1 kGy):
 - Inhibit sprouting
 - Delay ripening of fruits
- Medium dose (1 kGy to 10 kGy):
 - Extend shelf-life (seafood, fresh produce, meat products)

Principle Applications of Food Irradiation

- Low dose (up to 1 kGy):
 - Inhibit sprouting
 - Delay ripening of fruits
- Medium dose (1 kGy to 10 kGy):
 - Extend shelf-life (seafood, fresh produce, meat products)
- High dose (above 10 kGy)
 - Sterilization of spices, dry vegetable seasonings
 - Sterilization of hospital foods

What is FLUKA?



FLUktuierende KAskade is a versatile tool for calculations of particle transport and interactions with matter.

What is FLUKA?


FLUktuierende KAskade is a versatile tool for calculations of particle transport and interactions with matter.

- Accelerator shielding to target design
- Activation
- Dosimetry
- Detector design
- Medical applications e.g. treatment planning

FLUKA simulations




Dose depth plots for 10 MeV electron beam





- Electrons penetrates depth of approx 5 cm
- Single-sided E-beam irradiation
- Conveyor system used for double-sided irradiation
- If areal density $> 8.5 \text{ g/cm}^2$, X-rays used

E-beam to X-rays conversion



- Use high-Z (Ta-target) to convert electrons to X-rays
- Optimum thickness 1.7 mm
- X-rays for treatment of high density products





Dose distribution on meat



Photon distribution plots



Dose Equivalent plots






Design an optimal radiation-shielding infrastructure for the Rhodotron facility

Characteristics of the Rhodotron accelerator

- A compact continuous-wave high intensity industrial recirculating electron beam accelerator.
- $1 \text{ MeV} \leq E \leq 10 \text{ MeV}$.
- Relatively new



Rhodotron industrial applications



A typical Rhodotron facility layout



Acknowledgements

