



Politechnika
Wroclawska


Numerical Modeling of Superconductors and Their Application for Magnetic Shielding



Supervisor: dr inż. Łukasz Tomków
Veksler and Baldin Laboratory of High Energy Physics

Błażej Skiba
Wrocław University of Science and Technology, Poland
Faculty of Mechanical and Power Engineering,
Refrigeration and Cryogenics

Table of contents



- Introduction
- Superconducting properties
- Magnetic shielding
- Experimental setup and results
- Summary

Introduction

- Numerical and experimental investigating of SC shields
- Results for Electron Cooling System for NICA collider




Figure 1 Nica complex

Electron Cooling System

- Decreases the velocity range of ions
- Requires high homogeneity of magnetic field
- Usage of HTS screens for lowering the costs




Figure 2 Scheme of Electron Cooler

Superconducting properties

- Perfect conductors
- Meissner effect
- Described by critical parameters
- Classification:
 - LTS and HTS
 - type I and type II




Figure 3 Superconducting critical parameters




Figure 4 Critical magnetic field and Meissner effect in first and second type superconductors

Magnetic shielding

Two types: **open** and **closed**

Homogeneity of magnetic field

Trapping/Separating magnetic field

Applications:

- Cryocoolers
- Magnetic levitation systems
- Medicine
- Particle accelerators
- Superconducting synchronous machines




Figure 5 Examples of magnetic shielding application: ECS (top left), MRI (bottom left) and G-M Cryocooler (right)

Shielding effect




Figure 6 Results of numerical modeling – comparison of shielding effect

Shielding effect




Figure 7 Results of numerical modeling – comparison of shielding effect

Experimental setup




Figure 8 Experimental setup - connections scheme

Operating range of the magnet




Figure 9 Current – voltage characteristic of the superconducting magnet

Experimental results




Figure 10 Results of magnetic screening

Results and summary

- Maximum safe current for test stand magnet is ~ 20 A
- Open-type shields allow to increase field homogeneity
- Experiments will be continued with higher currents

Thank you for your attention!